# **Access Panels**



Rev 1.0 - August 2023 | **SEL-PRT-01478** 

# **Operation & Maintenance**

Please call for any further information 020 3880 0339.

## **Operation**

Via Access Panels have either a centre lock operated by a square key, a 3-point lock, a 3-point lock secured by a keyed euro cylinder, or a touch catch.

The 3-point lock, (on its own), only requires the square key to gain access. The combined 3-point lock and euro cylinder requires the key to be turned in the euro cylinder first, which will, in-turn allow you to operate the 3-point lock with the square key and unlock the door.

#### **COSHH**

Via Access Panels do not require COSHH information as they are manufactured from steel, with no hazardous materials.

## **Cleaning**

We recommend using a soft damp cloth with mild detergent on the powder coated finished doors. Do not use abrasive cleaners.

## **Fire Rated Doors IMPORTANT**

Fire doors should be checked every **6 months** minimum.

### **Maintenance**

Via Access Panels are a low maintenance unit. The parts to check on a regular basis are:

#### 1. Lock


Ensure the lock operation is smooth and lubricated. If required use a small spray of light oil (e.g. WD40). *Fig.*1

# 2. Hinges

Ensure the hinges are smooth and quiet. If required use a small spray of light oil (e.g. WD40).

### 3. Seals

Check seals are correctly positioned and not broken.



Door components can be replaced if damaged, please contact the Selo team to request these.

call 020 3880 0339 email sales@selo-uk.com

For further information on the Selo product range, including installation videos, O&M manuals, and more, visit our website:

www.selo.global/resources

